





Jan Vreeburg

Technische Universiteit Delft



Discolouration: Who's to blame








Beautiful stories on water treatment: but this comes out of the tap, even in the Netherlands




Drinking water distribution is a matter of skilled labour






Cast iron: the classic cause of discolouration (Ø100 Cast Iron, 1900)




\int

But: there is so little cast iron and still 3000 to 6000 complaints






The complete picture: Particle related processes in a network












Validate RPM result






The experiment with particle free water





Detail connection research area





Location



















The Research area



550 connections à 2,6 persons using 122 lppd (2004)
1970 AC part; PVC part 1974


The Reference Area





 520 connections à 2,7 persons using 118 lppd (2004)
1968-1969 AC part; 1st PVC part 1974; 2nd PVC part 1995-1999




Total volume particles







\int	Reference Area first period		Frequency percentile [%]	Ref Loc 1 [ppb]	[ppb]	Ref Loc 3 [ppb]
			90,0	14,57	2,95	7,55
	and the second		95,0	21,80	5,00	18,32
	Volume particles Reference Area		98,0	40,18	9,56	39,45
200,0 —			99,0	58,39	12,94	48,60
200,0			99,5	84,15	14,42	59,09
150,0 —			99,9	160,58	49,01	69,25
150,0 [qdd] amnov 50,0		- Ref Loc 1 - Ref Loc 2 - Ref Loc 3	ratio 90/99,5 average [ppb] surf -90 [%] surf +90 [%] Freq. distr. Refe	0,17 9,85 66,4% 33,6% rence area 1-	0,20 1,98 56,6% 43,4% 4-06 / 10-4-06	0,13 4,49 43,8% 54,9%
1-4-0	6 3-4-06 5-4-06 7-4-06 9-4-06	105,0				



Resuspension Potential Measurements Adjusted (100 m; 0,35 m/s, 5 minutes)

Points	0	1	2	3	4		
Max during disturbance [FTU]	<1	1 -3	3 – 5	5 – 10	>10		
Average during disturbance [FTU]	<1	1 -3	3 – 5	5 – 10	>10		
Resettling time [min]	<1	1-5	5-10	10-15	>15		


Research area Date		1 m 24-6		sure 005		-me 3-7				l-me 14-3				2-me 6-11		ure 006
location				tot				tot				tot				tot
Res loc 1	4	4	3	11	1	1	1	3	2	1	0	3	3	3	2	8
Res loc 2	4	4	4	12	1	1	1	3	4	3	0	7	2	1	0	3
Res loc 3	4	4	3	11	1	0	1	2				0	2	1	0	3
Res loc 4	4	4	2	10	0	0	0	0	1	1	0	2	1	1	0	2
Res loc 5	4	4	3	11	2	1	2	5				0	1	1	0	2
Res loc 6	4	4	2	10	3	1	1	5				0	4	2	0	6
Average				10,83				3,00				4,00				4,00

Reference area	-1 meas		sure	0-measure			ure	1-measure			2-measure					
Date	22-6-20		005 7-7-200)5	14-3-2006			6-11-20			006			
location				tot				tot				tot				tot
Ref loc 1	3	2	2	7	1	1	1	3	0	0	0	0	0	0	0	0
Ref loc 2	4	4	3	11	2	1	1	4	4	4	2	10	4	4	3	11
Ref loc 3	4	4	4	12	2	1	1	4				0	4	4	2	10
Ref loc 4	3	3	1	7	4	3	1	8	3	1	0	4	4	4	3	11
Ref loc 5	4	3	3	10	0	0	0	0				0	4	4	2	10
Ref loc 6	4	3	1	8	0	0	0	0				0	4	4	3	11
Average				9,17				3,17				4,67				8,83



RPM graphical

Average Resuspention Potential Measurement






How much sediment is accumulated: Clean both the areas

- Dedicated flushing program (1,5 m/s, uni-directional flow, clear water front)
- Continuous monitoring turbidity of flushed water
- Samples in first turn over flushed water
- Analysis samples for calibration curve TSS-FTU


Flush plans Research Area and Reference Area






Turbidity - TSS Reference area

Turbidity - TSS research area




Sample analyses


Composition flush samples Research Area




Composition flush samples Reference Area



Relative comp. flush samples Research Area



Relative comp. flush samples Reference Area



Removed TSS during flushing

	Total	Removed	Removed
	length	TSS	TSS per
	flushed		meter
	[m]	[gr]	[mg/m]
Research	5840	525,08	89,9
Reference	5370	5752,52	1071,2

Conclusion: sediment originates mostly from the treatment

What can we do in the network

Clean the network: Flush with water

- 1,5 m/s
- Clear water front
- 2 to 3 times turn over

Design on self cleaning networks




Clean the network: uni-directional flushing: a case study

The network of Venlo


- Partly Cast iron
- Partly Asbestos Cement
- Cleaning in 2002
- Treatment improved during 2004
- Monitoring with adjusted RPM

The network and monitor locations






The monitoring equipment







The results Average Adjusted RPM








Self cleaning networks: the principle



10.0



\int

Self cleaning networks: case study comparing to conventional network




\int


Self cleaning network



Area 1: conventional




Area 3: self cleaning




[©] Kiwa Water Research 2007

38





Comparison conventional ←→ Self cleaning Ratio In/Uit in different locations





Conclusions

- Sediment primairily originates from treatment
- Particle load in Reference Area reloads the system in one-and-a-half year to starting level
- Particle free water decreases cleaning frequency with factor 5-10
- Avoiding peaks will decrease the particle load significantly
- Dedicated flushing works
- Self cleaning network are self cleaning



″UDelft

Partner for progress

Jan Vreeburg

Technische Universiteit Delft



Particles in the distribution system





21-06-2007

